



Mueller
Human-Power

4893 Artino Ct. Eureka CA 95503 707-442-8133 mhp@Windwrap.com

Edge Trim (part SAET) Instructions

Thank you for purchasing edge trim from Mueller Human-Power.

When installing edge trim I recommend you warm it to 150 degrees Fahrenheit in the oven right before installing it.

1. Preheat the oven.
2. Check the oven temp with a thermometer.
3. Put the trim on a smooth surface like a clean cookie sheet.
4. Warm for about 5 minutes.
5. Using adhesive in syringe apply adhesive inside the trim using one 1/8th inch drop approximately every inch.
6. Install the edge trim while it is warm.
7. Trim with sharp scissors.

Warming the edge trim will stabilize its shape and length and make it easier to install.

If things just aren't working right please give us a call toll free. I will do my best to help you out. 1-877-267-1645

Wishing you lots of bug free smiling!

Mark E. Mueller

owner, Mueller Human-Power

Warranty:

MHP fairings and mounting hardware are warranted against manufacturer's defects for one year after purchase. MHP Fairings are warranted against cracking for one year if installed properly on MHP mounting hardware.

Disclaimer:

In no event shall Mueller Human Power be liable for any indirect, incidental or consequential damages from the sale or use of the product.



MHP Edge Trim Part # SAET

